

Oppsett forskjellige overganger til Weldon

DZFX-03		Fein Quick-In / 19,05 weldon (6,35mm pilot bore)
DZFX-04		Fein Quick-In / 19,05 weldon (8mm pilot bore)
DZCX-03		Universal / 19,05 weldon (6,35mm pilot bore)
DZCX-04		Universal / 19,05 weldon (8mm pilot bore)
DZLX-01		Fein M18*6/P1,5 / 19,05 weldon
DZCL-02		Universal / Fein M18*6/P1,5
DZCU-01		universal / 1/2-20UNF
DZXL-01		19,05 weldon / Fein M18*6/P1,5
DZXU-01		19,05 weldon / 1/2-20UNF
DZXZ-02		19,05 weldon / DIN238 B16
DZCZ-01		Universal / DIN238 B16
DZFZ-01		Fein Quick-In / DIN238 B16
DZXX-06		Arbor extension for 50mm
DZXX-07		Arbor extension for 75mm
DZXX-08		Arbor extension for 100mm
DZMZ-01		Morse taper 2 / DIN238 B16
DZMZ-02		Morse taper 3 / DIN238 B16



Oppsett forskjellige overganger til Weldon